


WEB PEGGY PARTS LIST

- | | |
|-----------------------|---|
| (1) Treadle bar | 1 |
| (2) Treadle board | 1 |
| (3) Dome Wood Screws | 2 |
| (4) Legs | 3 |
| (5) Main Block | 1 |
| (6) "Lozy Kate" pins | 3 |
| (7) Front Upright | 1 |
| (8) Back Upright | 1 |
| (9) "Mother of All" | 1 |
| (10) Nuts and Washers | 2 |
| (11) Wheel and axle | 1 |
| (12) Tension Upright | 1 |
| (13) Screw Hooks | 1 |
| (14) Flyer | 1 |
| (15) Bobbins | 4 |
| (16) Whorl | 1 |
| (17) Front Maiden | 1 |
| (18) Bearing Block | 1 |
| (19) Screw Maiden | 1 |
| (20) Crank | 1 |
| (21) Lock Nut | 1 |
| (22) Connecting Rod | 1 |
| (23) Dome Nut | 1 |
| (24) Nylon Spacer | 1 |
| (25) Leather strap | 1 |
| (26) Tension Knob | 1 |
| (27) Retaining Pin | 1 |
| (28) Threading Hook | 1 |
| (29) Spring | 1 |



For parts, please quote number and description.
Contact your supplier, or write direct to us.

RAPPARD & CO. P.O. BOX 1121, DUNEDIN, N.Z.

Copy right 1975